

General Checklist

Field Materials and Supplies

- Resurf® Resin (No Water!)
- Resurf Resin Catalyst (in jugs; Norox 925 or Hi Point 90)
- Resin faucet (2")
- Resin measuring pails (scribed)
- Catalyst measuring bottles (scribed)
- Resurf Aggregate Blend in Bags (keep dry!) Basic Directions on back of bags
- Resurf Accelerator, directions on label (may not be needed nor included)
- Bristle paint brushes (3-4" for priming) disposable
- Stirring sticks-disposable
- Numerous short pieces of 2x4 for tamping, screeding, and finishing
- Contractor wheel barrow
- 2 small mortar hoes or good strong garden hoes
- Assorted shovels
- 2-3 five gallon pails with lids
- Bung wrench or substitute, claw hammer, brick hammer, pick, hatchet, knife etc...
- Tape measure, chalk, markers
- Flashlight (day or night)
- Tarps or polyethylene film
- PPE (vest & safety gear)
- Kit: wire, tape, silicone caulk, string, rope, polyethylene foam rolls, bungee cords, note pad

Concrete evaluation, surface preparation and forming are covered in training videos and are somewhat job specific but aggressive sandblasting (when allowed) is extremely valuable and highly recommended.

We are always available for any project detail discussions.

Glenn Robinson: 334-412-2440