

RESURF® CRE

DIRECTIONS

1. Measure 2 parts A and 1 part B into a 2 to 5 gallon pail.
2. Mix well using a flat stirring stick; mix, scrape sides and bottom; mix again and repeat.
3. For larger batches, where as much as one gallon of A + B binder is mixed, a longer, sturdy 1" x 2" works well.
4. Quickly add large, double handfuls of RESURF® CRE Aggregate Blend while stirring vigorously until a very grainy and somewhat stiff mix is reached. This will still be pourable.
5. This mix can be used to repair very wet concrete (even underwater).
6. Make sure joint forming material is locked in place or weighted down before beginning to pour CRE to prevent material from floating out of joint.