



Polymer Concrete, Inc.

“Real World Solutions”

RESURF®II DIRECTIONS FOR USE

SOUND, CLEAN AND DRY CONCRETE IS REQUIRED

To prime the concrete surface, catalyze and mix the required amounts of RESIN (Note: the color change from reddish purple to greenish brown) Brush on.

Anytime within two hours (whether primer coat is gelled or not)

MEASURE:

a) 7.5# RESIN (one mark on scribed one gallon pail

b) One mark on pint catalyst bottle. MIX

c) Add to one bag RESURF Aggregate Blend (Yield = ½ cu. ft.)

MIX (quickly and well) until Aggregate Blend is evenly wetted. This should require about one minute or less.

1: 1: 1

1 mark: 1 mark: 1 bag

Fill hole (OVERFULL), tamp, trowel, screed. Finishing is aided by sprinkling dry

RESURF Aggregate on top while tamping, troweling and screeding.

Low or rough areas may be mended by painting (or puddling) with catalyzed resin and broadcasting to dryness with RESURF Aggregate Blend; screed to grade.

High areas can be shaved down to grade while polymer concrete is “cheezy” (20-30 minutes after placement). Use a square end shovel or hoe.

Return traffic within two hours or when repair cannot be penetrated with a thumbnail or pencil point. For more detailed information see:

www.RESURFII.com

Office: 334-682-4296

Glenn Robinson Cell: 334-412-2440

Email: glenn@RESURFII.com