

**Very Important TIPS for Using**  
**RESURF®II and RESURF®LR**

- Please read, communicate, and follow basic BAG DIRECTIONS and these TIPS before planning and starting work
- Everything must be kept DRY!
  - Aggregate Blend bags are not waterproof!
  - All Tools for measuring and mixing must be dry!
- Mixing tools must be kept clean
  - Scrape hoes, wheelbarrow, shovels, and finishing tools routinely. This is very, very important! It makes the mix finish much easier and perform much better. Hammer and chip wheelbarrow and hoes after completely cured, before beginning work, and while cool-cold.

1:1:1

- For 0.5 Cu. Ft. batch (one bag), Fill one gallon pail with Resurf Resin (to the mark) and add one mark of catalyst (from scribed bottle) and mix about 10 seconds
- Add this catalyzed resin quickly to clean/dry wheelbarrow and immediately and quickly spread entire bag contents over and into the resin (without splashing)

2:2:2

- For 1.0 Cu. Ft. batch (2 bag)
  - Fill supplied scribed 2 gallon pail to mark and add 2 marks catalyst (hardener)
  - Mix and quickly pour entire pail into wheelbarrow
  - immediately and quickly spread 1 (one) bag over and into resin
  - mix quickly and aggressively. It is very important to scrape bottom of wheelbarrow on each pulling stroke! Do not push hoe but pull while scraping bottom until no visible dry spots.
  - immediately and quickly spread the entire 2<sup>nd</sup> bag over the wet mix and again scrape the bottom with pulling strokes until no dry spots

GOOD & QUICK MIXING MAKES FINISHING A JOY AND ENHANCES  
PRODUCT PERFORMANCE

- Shovel or dump mix into and near prepared spall. Overfill and tamp aggressively. Do not drag forward to underfill spall or joint. Good consolidation makes the mix appear wetter, finish easier, and perform much, much better.

- All Resurf components should be protected (even for short periods) from the elements: rain, sunlight and heat
  
- ▽ Damp or wet aggregate blend is unusable!
- ▽ Water in resin will be milky and kill the cure reaction.
- ▽ UV (sunlight) degrades Resurf catalyst (hardener): Store dark & cool and check dates on bottles
- ▽ Dry pails and tools before use
  
- See separate sheet for Resurf Resin Reactivity Test and acceleration (if necessary) See directions from accelerator bottle.

If you have any questions or comments, please call 334-412-2440 or 334-682-4296

Email: [glenn@polymerconcreteinc.com](mailto:glenn@polymerconcreteinc.com)

Visit our website: [www.polymerconcreteinc.com](http://www.polymerconcreteinc.com) for training videos, procedures and other product information.