

DIRECTIONS FOR USING RESURF® VO-21
(2 TO 1) VERTICAL AND OVERHEAD (VO) EPOXY MORTAR

- 2 Parts (Epoxy) Side Is **White**
- 1 Part (Hardener) Side Is **Black**
- Place Approximate Size Scoop (pile) Hardener (black) on mixing board
- Place an equal size scoop (pile) of epoxy (white) on EACH side
- Mix Until Evenly Gray; No White or Black Spots or Streaks
- Prime Concrete by Rubbing Stiff Paint Brush in Gray Mix and Scrub into Concrete Surface
- Trowel on Vertical and Overhead (Press Firmly Into all Voids)
- If Spall is deeper than 2 inches, 2 or more layers may be needed

For Assistance Please Call Glenn Robinson:

Cell: 334-412-2440

Office: 334-682-4296

Home: 334-682-4566

Resurf® is the registered trademark of Polymer Concrete

