SINGLE POINT LESSON- ACCURATE WORK ORDER CLOSE OUT

BY: RICKY SMITH, CMRP, CMRT, CRL







Single Point Lesson

ACCURATE WORK ORDER CLOSE OUT

by Ricky Smith, CMRP





"Accurate Work Order Close Out is important for the continuous improvement of any Maintenance Organization / Asset Reliability."

Maintenance Scorecard

January 2020









The objective of accurate data collection is to assist management in making the right decisions at the right time and to empower workers to make decisions at the floor level.

Work Orders are NOT:

A•method to track whether a Maintenance Technician is working or not (Maintenance Supervisor's responsibility)

• A waste of time (it takes less than 2 minutes to write a work order for any maintenance action required)

Work Orders are used as a...

- A method to identify repeat failures in equipment (typically "Bad Actors")
- A method to track maintenance repair and parts cost on specific assets to determine when action is required to restore equipment to a "Maintainable Condition."

A•method to track specific parts (ie. Bearings) are being consumed at an increased rate with the possible root cause could be identified to one of two causes.

General Rules of Work Orders

Work Orders should have at the minimum the correct code (breakdown (1), urgent (2), etc., the correct equipment number, at the right level, the maintenance person's accurate total work hours charged to this work order, the start time and complete time on the job, comments from the maintenance person as to what work was performed or any recommendation to changes to maintenance strategy or plan, any parts used whether from the storeroom or not.

Without the above information one cannot determine: Actual maintenance cost for specific assets

Mean Time Between Failure (MTBF)

Mean Time To Repair (MTTR)








- Mean Time Between Repairs (MTBR)
- Rework
- If a PM Procedure is effective
- If a specific type of repair is effective

#1

Repair or Corrective Work orders should have the information as stated above everything as stated above plus, component code, failure code, and cause code if an organization wants to mitigate unexpected failures.

Without the right information on work orders when closed one cannot determine:

Dominant Failure Thread – which component has the most specific failure modes with a specific cause across multiple assets.



 <u>Dominant Failure Pattern</u> – which failure pattern is the most dominant and what are the major causes of failures for this pattern. This allows one to develop strategies to eliminate unacceptable failures which impact the organization.

#2

Establish the Criteria for WO Order Priority (all work orders are not equal).

See chart below to illustrate work order priority levels, time to respond, consequence of delaying the work, and likelihood of failure.







Priority	Description	Time to Respond	Consequence of Delaying Work	Likelihood of Failure
1	Emergency	Within 24 Hours	Injury or Death Major (Total) Production Loss Regulatory/Environmental Violation	Immediate Failure Certain
2	Urgent	This Business Week	Significant Production Loss Product Quality Issues Significant (Avoidable) Repair Costs Secondary Equipment Damage	Immediate Failure Probable
3	Standard	Within Next 2 Weeks	Loss of Production Rate – Slowed Production Spurious Interruptions to Production Capability Minor Product Quality Losses All Proactive Work (PM and PdM)	Immediate Failure Unlikely
4	Non-Critical	> 2 Weeks	Strategic Improvement Work Construction and Capital Projects No Immediate Impact on Safety, Compliance, Production, or Costs	Failure Not Likely

#3

Preventive Maintenance/Predictive Maintenance Work Orders should... Become a method to track, prevent or predict known failure modes (failure mode – how something fails, example: Lack of Lubrication)

- •Attach the equipment history for the past 30-60 days to the PM and provide time on the schedule for techs (10 minutes max) to review before they execute the PM.
- On a PM Procedure it should have specific steps and specifications on what is to be done to known best practices.

Example: Lubricate Bearing -

- Step 1: Clean the grease fitting.
- Step 2: Clean the end of the grease gun to ensure no contamination will be introduced into the bearing.
- Step 3: Insert 4 grams of lithium grease (two shots)







#4

When closing all Work Orders the following items should be included:

Condition as Found.

Condition as Left

Recommendation to changes to procedure.

Hydraulic System Yearly PM			Hydraulic System Yearly PM Required Departmental Coordination: Describe Connectional Control of Wesley Scheduling Marring			Hydraulic System Yearly PM		
Equipment Herandry.					Procedures Referenced. If Yagast XYZ			
Cautions	Downtime: Tany Millsop Mont Value	Very Very versit in environ in could result in pr	invarion Date: 06/26/2008 1 1.0	10	Description Locked Tagod Description Coron Reserves One Intel Interview Coron Reserves Other Intel Interview Coron Intel Intel Reserves Venich Longert Informatic Intel Intel Reserves Venich Longert Lock Intel Reserves Reser	Count	Consider (As Left) Commercial:	
Roinfenance Shop Roinfenance Shop 532140056	FMO-500-AW OII Lint Free Toxels On Filter Element	2 2	Gallone Baress each				Craft's Feedback on Procedures:	
Consumables Needed Degresser, paper for							Craft's Signature(s):	
Special Tools Require Transfer Filter Russ								
Mobile Special Equipment	nent.						Outs:	
Page 1 of 3				Page	d of 3		Page 3 of 3	

#5

Define Roles and Responsibilities for the effective use of Work Orders using the RACI Model.

• Assemble a team of people involved in Maintenance Work Order Success (ex: planner, supervisor, technician, reliability engineer, production).

Define the WO process/ tasks required for success.

Educate the team in what an effective Work Orders looks like.

Prepare key people before you assemble the team.

Facilitate the team through the RACI Process.

Post the RACI Chart along Maintenance KPI Dashboard for all to see .

Perform RCA when WOs that do not meet expectations.

See example chart on the next page for a RACI chart.







Maintenance Work Order Roles and Responsibilities "RACI"

Tasks Decisions/Functions	Maintenance Supervisor	Maintenance Planner	Production Supervisor	Maintenance Manager	Production Manager	Technician
Create a Corrective Maintenance Work Order	R	С	R	I I	A	R
Create an Emergency / Urgent Work Order	R		R	A		
Approve Work Order	R	R	С	A		
Parts charged to Asset via Work Order	R	A				R
Ensure WO Info Correct Before Closure	R	A				С
Close Out WO	С	R	С	A		С
Leading/Lagging KPIs Reported	1	R	1	A	1	L

Responsibility
Accountable
Consulted
Informed

"the Doer" "the Buck stops here

"in the Loop"

"kept in the picture"









#1 Software for Maintenance & Reliability Teams

UpKeep is a service-first company that builds software designed to make maintenance easier for technicians and managers everywhere. Reduce downtime up to 18% by switching over to a preventative maintenance solution!

www.upkeep.com

Our Products



Mobile-first maintenance management and collaboration across all location, assets, and teams

With nearly 340 different machines in our work environment, it's an impossible task to manually assign and track PM's. With UpKeep we can schedule regular maintenance without overlapping tasks with other critical jobs."



Paul D, Health and Safety Coordinator



An end-to-end solution for remote condition-based monitoring

Connected and secure IoT sensors for real-time remote condition asset monitoring





Integrated & Centralized Data Ecosystem for World Class Asset Operations

The only purpose built Asset Data Platform. Asset Focused ELT Solution for advanced analytics and integrated, real-time asset data.

The Maintenance Community Coalition was founded on the belief that working together will benefit everyone within our community

Committed to helping each other thrive in our individual professional journeys by sharing resources and expertise, granting scholarships, hosting events, and unlocking knowledge – always at no cost.



