

1. To simplify this install you can easily remove the glove box door from your car to do this on your bench. It is not necessary to do so, but it does make it easier.
2. Remove factory knob and latch. To remove, support the glove box door with one hand while slightly twisting and pulling on the latch.
3. Once you have removed the factory knob and latch, clean the steel ring on the front side of the door. Also clean the plastic surface around the hole on the interior side of the door.
4. Apply a light layer of grease to the steel ring.
5. Apply a small amount of grease to the detent ball on the billet knob.



6. Place the billet knob onto the glove box door so that the logo is straight up and down.



7. Apply a small amount of blue Loctite onto the supplied 10/32x5/8 button head cap screw.



8. Install billet latch to the back side of the billet knob and tighten screw.

**If you have any questions, please contact me.**

**Thank you for your business!**

