

With proper care, Crystal cabinetry will provide a lifetime of use and satisfaction. Proper care includes providing a wood friendly environment. Many of the internal environmental issues that affect human comfort also contribute to a wood healthy environment. Specifically, controlled temperature and humidity with minimal changes from day to day and season to season will ensure your comfort and they will ensure the stability and life of your wood cabinetry.

Moisture

- Repeated short term exposure to excessive moisture such as splashing of surfaces from a sink or even a single longer term event such as flooding WILL result in irreversible damage to wood cabinetry and furniture.
- Steam, as from cook tops, crock pots and improperly sealed dishwasher doors, can cause problems as well.
- Moisture should be wiped from surfaces immediately to minimize damage.
- If wood has a chance to absorb excess moisture, efforts should be made to dry out the wood including substrates immediately.
 - Avoid direct high heat and instead use fans and dehumidifiers and moisture absorbing cloth and compounds.
 - Immediate attention reduces the amount of damage and also reduces likelihood of mold and mildew.

Humidity

- Wood expands as humidity increases and shrinks as humidity decreases.
- Unfinished (exposed) wood will exhibit the most dramatic changes
- Even finished wood will change with long term changes in humidity.
- Finishes and other coatings such as laminate or foil temper humidity swings by slowing the transfer of moisture.
 - They do not stop it entirely.
- Solid wood will dimensionally change more across grain than with grain.
- Plywood, particleboard and fiberboard are more dimensionally stable.
- Particleboard and fiberboard, exposed to water directly, will expand in thickness quickly and dramatically.
- As wood expands (swells) and contracts with changes in humidity, the finish at joints will crack.
 - This cracking is universal but is much more evident on light colored paint than on stains or dark paints.
 - Regardless, this is the nature of product made from wood and not a reason for replacement.
- Where humidity exposure is uneven, pieces may warp, cup or bow.
 - Most often, if humidity level is returned to a normal level and maintained for a period of time, these issues will disappear.
- Extremely dry conditions can result in wood parts splitting and / or cracking in addition to shrinkage as described above.
- The optimal humidity level is 35% to 50% relative humidity.
 - Extreme conditions (lower than 20% or higher than 80%) especially need to be avoided.

Humidity Continued (Dryness)

While most focus is on too wet (damp) or too humid conditions, too dry conditions can be equally damaging to cabinetry.

- Extreme dry conditions can lead to cracking in solid wood components.
- Under dry conditions, the insert panels in panel doors will shrink and the panel edges will be exposed.
 - Exposed, unfinished panel edges will not match finished surfaces of the rest of the panel and door.
 - This is not a reason for replacement but is instead an indication that humidity levels are too low and need to be remedied.

Temperature

- Temperature variation can cause some of the same problems as humidity variation and the two are often interrelated.
 - Temperature increases cause materials to expand.
 - Temperature decreases cause materials to contract or shrink.
- Sudden temperature changes cause more dramatic material changes.
 - More likely to lead to cracking, and splitting in solid wood.
 - More likely to lead to warping, cupping and bowing in any wood components.

Remediation

- Use dehumidifiers and / or air conditioners in summer to control excess humidity.
- Use a humidifier to keep the air from becoming too dry in winter.
- Maintain climate control during the off season of vacation homes to reduce the risk of damage.
- Prior to installation of new cabinets, acclimate cabinetry by moving it into the room it will be in when done.
 - This should be done well in advance of the installation.
 - If this is not possible, use an adjoining room of similar climate conditions.
 - Do not store in a garage, basement or other unheated or unconditioned space prior to installation.
- Temperature and humidity are also affected by:
 - Proper outside drainage.
 - Adequate insulation.
 - Properly installed vapor barriers.
 - Adequate and proper ventilation and air exchange.

Summary

Remember: Properly controlling temperature and humidity inside the house is healthier for the inhabitants as well as for the cabinetry and furniture within.

A NOTE ON SINK BASES FROM CRYSTAL CABINETS



Most of our sink bases do not require an extra liner or other treatment to protect against chemical and moisture damage like sink bases from other companies. Our melamine and clear finished maple and basswood veneer interiors are both impervious to moisture and can withstand protracted exposure to water and household cleaning products. Extra precautions should be taken with the Natural Maple Foil interior for the Current lines which is NOT impervious to moisture.

If holes are drilled through the bottom for plumbing and / or wiring, at a minimum, the edges of the hole(s) should be carefully sealed to prevent moisture from coming in contact with the substrate. The better approach would be to cut the minimum size hole(s) needed and, after the plumbing and wiring is done, completely fill the remaining space with a high quality caulk to prevent moisture from getting to the substrate and / or passing into the space under the cabinet. At the same time a narrow bead of caulk around the perimeter of the cabinet bottom will prevent moisture from seeping into the cabinet joints where damage to the substrate can occur.