

Hull Preparation for **QuickSlick**

- 1. Rough gelcoat with 24 grit sanding disc on grinder.**
*to ensure proper adhesion, remove any existing bottom coating that is not **QuickSlick**
- 2. Blow dust off (with airhose).**
- 3. Wipe prepared hull with lightly moistened acetone rag to remove remainder of dust particles.**
- 4. Tape and mask off remainder of exposed hull.**
- 5. Mix bottom well (drill with paint stirrer works best).**
- 6. Add hardener-30cc per 1 gallon (mix thoroughly).**
*can be reduced to 25cc per 1 gallon for longer working time or in high temperatures
*can be increased to 35 cc per gallon when temperature is below 70 degrees
- 7. Apply **QuickSlick** to hull.**

**hull should be COMPLETELY moisture free and application should be done immediately after preparation

***any questions regarding preparation or application, feel free to call **Brian** at **(863)581-9710**

**** suggested coverage 1 gallon per 20-25 square feet

Warning!

Keep out of reach of children.

Avoid contact with skin and eyes.

Mix and apply in a well ventilated area with proper safety gear.