

DESCANSO SERIES: CARPET TILE INSTALLATION INSTRUCTIONS

Basics

CPI has adopted the Carpet and Rug Institute's "Standard for Installation of Commercial Carpet," (CRI 104) (www.carpet-rug.org) as the basic minimum industry guideline for the installation of Descanso Series carpet. Please note, however, that the instructions for some specific styles may exceed the basic minimum requirements set forth in the CRI 104 Standard. When consulting the CRI 104, please make certain it is the most recent edition and contains the latest updates. Copies may be obtained on the CRI website.

Layout

Confirm the End User's preferred layout prior to beginning work. If there are questions about the recommended layout, please contact CPI prior to starting installation of any carpet tile style. CPI's product design team determines the recommended layout for every style to maximize the final appearance of the product. Carpet tile seams will never be invisible and are usually most visible on the day of installation. Seams become increasingly less visible once acclimated to the interior and with routine vacuuming and foot traffic.

24 in x 24 in Carpet Tile:



ASHLAR



BRICK



MONOLITHIC



QUARTER DROP



QUARTER TURN



RANDOM

Floor Preparation

Carpet and Rug Institute Carpet Installation Standard for Commercial Carpet and Rug Institute. In addition to the specific instructions detailed here, the CRI 104 must be closely followed as basic minimum requirement for floor preparation and installation on all carpet installations CRI104 can be downloaded from <https://carpet-rug.org/resources/installation-standards>

Concrete Sub-Floor

All new concrete must be fully cured, clean, and dry. Old concrete must be clean, dry, level, and free of paint, dirt, old adhesive, oils, or other contaminants. The concrete should be free of curing or parting agents that interfere with the bonding of the adhesive. Whenever a powdery surface is encountered like lightweight concrete, a sealer compatible with the adhesive, such as Taylor 2025 Primer or an approved primer, must be used to provide a suitable surface for direct glue installation. Level the floor to the standards outlined in the American Concrete Institute specifications for Concrete Building ACI 301 in regards to trowel finish and finishing tolerance. Leveling compounds must be Portland-based cement.

Patch cracks and holes with one of the following approved patching compounds: Ardex Feather Finish, Ardex K-15, Henry's 547, Mapei Plani Patch, or similar cement based compound. Do not exceed manufacturer's recommendation for patch thickness. Gypsum based compounds are not recommended.

DESCANSO SERIES: CARPET TILE INSTALLATION INSTRUCTIONS

 CATALINA
PRODUCTS
INTERNATIONAL
714.716.1667 | contact@catalinaproducts.international

Page 2

Note: Incompatible adhesives, solvent-based materials, and other contaminants should be removed 85-90% and encapsulated prior to installation of carpet.

Contact CPI for further information at 714-716-1667 or email contact@catalinaproducts.international.

Other Substrates

Underlayment grade OSB, APA registered underlayment plywood, Gypsum or lightweight concrete must be primed with Taylor 2025 primer.

Test Conditions

Testing is not required when using CPI Alliance Adhesive, Taylor Dynamic, or Bentley Healthbond 2399 adhesive. No RH testing, no pH testing, no intact.

Note: Hydrostatic pressure is not an acceptable condition of the substrate. Hydrostatic pressure is the occurrence of the concrete slab being hydrated from below or water under the slab pushing up through the surface. This is visually seeing effervescence or alkaline salts carried with water on the surface of concrete and occurs with "on grade" or "below grade" concrete.

Installation Instructions

Conditioning Carpet Tile

Let the carpet tile acclimate prior to installation. The amount of time necessary for conditioning will depend upon potential temperature extremes during storage. Carpet tile subject to extreme temperature fluctuations will require more acclimation time than carpet stored in acclimate-controlled building. During periods of high humidity more time may be required to allow the carpet tile to acclimate. CPI Alliance and Bentley Healthbond 2399 adhesive is water-based and may need more time to flash off prior to placing carpet tile onto the adhesive. Ideally, the carpet should be allowed to acclimate in the space to be carpeted for 24 hours whenever possible.

Note: CPI cannot be held responsible for carpet stability issues such as curl, dome, expansion, or contraction when carpet is not properly conditioned prior to installation.

Centering/Squaring

Divide the room into four quadrants and snap a chalk line and seal it. Make sure quadrants meet at right angles. Take care to keep perimeter carpet tile cuts larger than half size or 9 inches. Once the chalk lines have been established at right angles in the center of the room, install only one carpet tile. This first tile should be placed snugly in the corner formed by the 90-degree angle of the chalk lines with two sides of the tile aligned along two chalk lines of one quadrant. Repeat procedure on remaining quadrants. Arrows are printed on the back of carpet tiles, for consistent installation direction. For monolithic installation, make sure arrows point in the same direction throughout the installation.

DESCANSO SERIES: CARPET TILE INSTALLATION INSTRUCTIONS

 CATALINA
PRODUCTS
INTERNATIONAL
714.716.1667 | contact@catalinaproducts.international

Page 3

Through Doorways

In order to spread adhesive throughout the room and allow for a single set-up time, an additional perpendicular line should be established and squared from the center line of the room to run through doorways before application of adhesive begins.

Care should be taken to measure a distance equal to an even number of carpet tiles from the room's center line to a point in the doorway. This point in the doorway will determine where the first tile is installed. This allows the installer to begin a square installation in the doorway without having to track back through the adhesive.

Adhesive and Adhesive Application

Approved Adhesives: CPI Alliance Adhesive, Taylor Dynamic, and Bentley Healthbond 2399 Pressure Sensitive Adhesive

The above Pressure Sensitive Adhesives require a full spread application for Descanso Series Carpet Tile Installations. Once the floor has been properly prepared as detailed in CRI 104, adhesive should be applied to the entire area prepared to receive carpet tile. This will prevent lateral shifting due to regular foot traffic and will ensure a successful installation of Descanso carpet tile. After carpet is in place, all full spread installations must be rolled with a 75 - 100 lb roller to ensure proper adhesion.

Descanso Assured™ Hardback Tile: Use a 3/4" nap paint roller. Spread rate is 27-34 yards per gallon.
Descanso Altai Plus Cushion Tile: Use a 1/16" X 1/16" X 1/32" u-notch trowel. Spread rate is 25-30 yards per gallon.