

CustomshuttersGuru

www.customshutters.guru

HOW TO REPLACE STAPLES ON TILT ROD AND LOUVERS WITH BRASS SCREW EYE AND HOOKS

Tilt rod with hook and eye replacing staples



Tools needed; pencil, pliers-regular or needle nose, ice pick/small nail, caulking

Firmly hold shutter tilt/control rod and with pliers begin pulling out the staples from each louver. Once complete remove tilt bar and place to the side for now. With a pencil mark the center between the staple marks on each louver. At the marks take the brass screw eyes from the kit and screw into the marked spot of the louvers with eye pointing straight out from the louvers (see pic). An ice pick or a small nail can be used to make a starting hole. At this time take a small amount of caulking and fill the staple holes on each louver.

Now take the tilt rod and remove the staples in the same manner. Also, in the same manner as before mark the center spot of the staple holes. Next take the brass screw hooks and screw into the tilt rod with the hooks facing straight out from the control rod. At this time apply caulking to the staple holes.

Next, take the tilt/control rod and connect the hook attached to tilt rod into each louver eye screws and with pliers close the hook. (see above pic)

See our (Tilt Rod Staple Replacement Kit) in our on-line store.