

Lenovo 100e Rugged case install.



Top (Screen side)

1. Install the top edge first insuring the 4 catches are hooked on the top side of the screen.
2. Swing the case on and the side screen catches should hook on.
3. Insure the case is fully installed by checking the corners near the hinges.



Bottom (Keyboard side)

1. Hook the catches in near the mouse pad.
2. Clip the rear two catches in.

