

Fender Bra Dealer Installation Instructions

2 - Fender Bras
8 - Male Snaps
10 - 1/8 rivets

ALL ORDERS ARE DOUBLE CHECKEI TO ELIMINATE SHIPPING ERRORS.)
FILLED BY:	
CHECKED/PACKED BY:	

- 1. Carefully place the fiberglass template on the fender.
- 2. Mark the four holes to be drilled with a marker or wax pen. <u>Do not drill</u> through the template.
- 3. Remove the template and drill four 1/8 holes in the fender.
- 4. Install four rivets with the male snap on them on the previously drilled holes.
- 5. Snap the outside lower snap first working in a clockwise pattern snap the bra into place.
- 6. Repeat for the other side.



THIS FABRIC CONTAINS 65% POLYESTER AND 35% RAYON BACKING

WARNING: This product can expose you to chemicals including Di-iso-nonyl Phthalate which is known to the state of California To cause cancer and birth defects and/or other reproductive harm. For more information go to: www. P65Warnings.ca.gov PRODUCER: CHINA GENERAL PLASTICS CORP.

FROM ALL OF US AT CALIFORNIA SIDECAR. ENJOY THE RIDE.