

Daytona

BY **CSC**
TRIKES

2014 - Current

FLHT Series Harley-Davidson

**POWER TRAK
Installation Instructions**

REVISED 1 - 2015

**California Sidecar Parts & Technical Support
434.263.8866**

Warnings and considerations:

- 1.Disclaimer** - These instructions assume a level of understanding of motorcycle repair and maintenance beyond that of a “beginner” and/or “novice” and California Sidecar cannot be liable for an installer’s failure to understand or follow these instructions as written. Likewise, California Sidecar cannot be responsible if any of the steps are omitted or shortcuts are taken, or parts other than those supplied by California Sidecar are used.
- 2.“WARNINGS”** are all printed in bold type and capitalized. They mean to use extreme care in a given step so as not to damage the part, motorcycle, and/or yourself.
- 3.Always** wear safety glasses when using hand and/or power tools.
- 4.**When working in and around the fuel system, **always** work in a well-ventilated area, free from sparks and open flames.
- 5.**All directional references to the “right side” and the “left side” are as you were seated on the motorcycle.
- 6.**All directional references to “forward” mean to the front of the motorcycle while “back” means the rear of the motorcycle unless otherwise stated.
- 7.Warning:** The fork spring cap is under spring pressure; use care when removing it.

Disassembly:

1. Refer to the Service Manual for the model Motorcycle that you are working on for disassembly.

Fork tube extension installation:

1. Remove OEM fork cap and install CSC fork slugs. Reuse stock o-rings from the caps.
Torque to spec.

Power Trak Triple Clamp Installation:

1. Install the new lower triple clamp after greasing lower bearing. Use multi purpose grease. Install steering stem bolt and hand tighten.
2. Torque to 35 Ft.- Lbs.
3. Turn lower triple clamp left and right a few times and recheck Torque. 35 Ft.- Lbs.
4. Install top triple clamp over steering stem bolt.
5. Install fork tubes and refer to service manual for tightening and torque procedures for the triple clamps and fork tube pinch bolts.
6. Torque fork tube pinch bolts to 25 Ft.-Lbs.
7. Torque steering stem pinch bolt to 35 Ft.-Lbs.
8. Install the CSC extended length Fork Slider Covers with 1/4-28 x 1 3/4 HHCS.
9. Reassemble in reverse order.

**From all of us at California Sidecar.
Enjoy the ride!**