

2" Lift Kit for Kawasaki Brute Force 650i 750i 2005-2024

Front Lift

1. Place jack under center of ATV front end and lift until front wheels clear the ground. Be careful to support ATV properly so that it is securely supported but so that A arms and shocks can drop to full extension.
2. Remove front wheels.
3. Disconnect the top of the shock from the shock mount.
4. Slide the long front lift bracket next to the frame. It should run from one shock mount to the other, on the front side. THE FRONT BRACKET IS THE LONGER OF THE 2 LARGE BRACKETS, THAT DOES NOT SAY LUCKY 7 ON IT.
5. Next place the spacer in the shock mount tab loosely securing it with the small lift bracket and 10x60 bolt and 10mm lock nut
6. Now connect the top of the shock to the lift brackets using your stock hardware
7. Tighten all lock nuts and repeat steps for opposite side.
8. Place front wheels back on ATV and torque lugs to factory specifications.

Rear Lift

1. Place jack under ATV at the rear of the bottom skid plate and lift until the weight is off of the suspension. Be careful to secure the ATV properly so as not to fall off the jack.
2. Remove the top of the shock from the shock mount.
3. Insert the long rear lift bracket in place. (It will go towards the rear of the bike, and you should be able to read Lucky 7 Left to right
4. Place the spacer in the shock mount and the small lift bracket to the rear of the frame holding it in place with the 10x60mm bolt and fasten with 10mm lock nut.
5. Then connect the top of the shock to the lift brackets, Using factory hardware.
6. Tighten all bolts.
7. Place wheels back on ATV and torque all lugs to factory specs

*Depending on year model, you may have to remove the factory sway bar.