

## 2007-2024 Grizzly / Kodiak 550 700 High Clearance Metal Floorboards

---

1. Remove factory floorboards and footpegs, save the factory hardware as you will be reusing some of it for the install.
2. Clean support area if desired.
3. Install new Lucky 7 floorboards, using the provided mounting bolts. (8) M6x16mm
4. Use factory hardware or the included M6 button head bolts and nuts to bolt the floorboard to the fenders, finger tighten all hardware for now.
5. Use the included 4 M6 button head bolts and nuts to attach side cover on Left side.
6. Make needed adjustments to align floorboards with bike and allow clearance for belt box and brake lever.
7. Tighten all hardware.