

Low Profile Polaris Sportsman 550 850 1000 XP SP Radiator Relocation Kit 2009 - 2024 with Mesh

1. Remove radiator from factory location. On some models you may need to remove the fan from the radiator to remove the assembly from the 4 wheeler.
2. Place radiator into kit, placing rubber feet into the radiator kit, then placing the radiator in the rubber feet. Lean the radiator to the top, and secure the radiator to the kit using included m6 1.0 x 70mm bolts, spacers, and Nylock nuts.
3. Figure out where you are comfortable cutting your plastics and running your coolant hoses.
4. Extend Lower hose using included couplers and hose clamps, and make connection to radiator.
5. Repeat Step 4 with the upper hose.
6. On some models, you will need to extend the fan wiring, which will be up to the customer. The positive and negative wires will need to be extended no more than 8".
7. Once the fan is wired, and radiator hoses are connected, fill radiator and complete the bleeding process.
8. Radiator overflow can be relocated, or kept in the stock location.
9. Secure radiator kit to rack using hardware of your choice. This hardware is NOT included, as this kit fits many models, and there are many ways to secure it. If you have the plastic rack, I recommend using bolts, and washers on the bottom of the plastic to secure it to the rack.
10. Enjoy.