

Yamaha Grizzly / Kodiak 550 / 700 Radiator Relocation Kit Powder Coated Low Profile Mesh 2014-2024

1. Remove Radiator from factory location, don't forget to drain first.
2. Place radiator in cradle, bolt top of radiator using the included spacers and long bolts / nuts. Mach up where coolant lines, and fan wire are going to be ran.
3. Cut holes / Extend coolant lines using included hose connectors and clamps.
4. Fill radiator, and bleed. Relocate fill neck if necessary.
5. Last step is to bolt down the radiator kit to the rack.

Give us a call if you have any questions.