

## 2016-2024 Polaris Sportsman Highlifter 850 & 1000 Metal Floorboards

1. Remove factory floorboards by removing push pins, and 4 Bolts securing the floorboards to the floorboard supports. Keep all 8 floorboard bolts, as you will need them to attach the new Lucky 7 Floorboards.
2. Clean floorboard supports, and place Lucky 7 floorboards on Clean supports. Secure loosely using the factory bolts.



3. Using the included M6x1.0 Hardware attach footpegs to floorboards if purchase.
5. Drill plastics as shown in photos to allow M6x1.0 Bolts/Nuts to secure the floorboards to plastics.



6. Install Side Plate using 4 M61.0 Bolts and Nuts



7. Tighten everything down / Enjoy!

