

## 2017-2024 Polaris Sportsman 850 SP 1000 XP Metal Floorboards Footwells

1. Remove factory floorboards by removing push pins, and 4 Bolts securing the floorboards to the floorboard supports. Remove plastic Floorboard Base, Our floorboards attach directly to the metal frame
2. Clean floorboard supports, and place Lucky 7 floorboards on Clean supports. DO NOT BOLT THE FLOORBOARDS DOWN TO THE FRAME UNTIL THE END .
3. Using a 1/4" Drill Bit, Drill plastics in the middle bolt hole, using the floorboards as a template (shown in photos) to allow M6x1.0 Bolts/Nuts to secure the floorboards to plastics.



4. On the Right (Passenger side) Rear part of the floorboard, you will want to use the longer M3x30mm Bolt as shown in the photos, to secure to the factory heat shield, and use one of the push pins removed during installation, to secure the inner most tab.



5. Tighten down all bolts securing floorboards to the plastics
6. Install Passenger Side Plate using M61.0 Bolts and Nuts
7. The Passenger Side Driveshaft cover bolts to the back side of the floorboard closest to the frame, using 3 included M61.0 Bolts and Nuts
7. Tighten the bolts securing it to the frame down, you will have to move the floorboard about 1/4 inch to allow holes to line up on the frame.