

2021 and up Polaris Sportsman 450 & 570 Low Profile Mesh Radiator Relocation Kit

1. Remove Radiator from factory location, don't forget to drain first.
2. Place radiator in cradle, bolt top of radiator using the included spacers and long bolts / nuts. Mach up where coolant lines, and fan wire are going to be ran.
3. Cut holes / Extend coolant lines using included hose connectors and clamps. (You may also need to extend fan wires for installation, depending on model)
4. Fill radiator, and bleed. Relocate fill neck if necessary.
5. Last step is to bolt down the radiator kit to the rack.

Give us a call if you have any questions.