

Can-Am Outlander 500 & 700 Rear Rack 2023-2024

1. Remove 4 Bolts from the rear tray on the factory rack.
2. Loosely install the Rack Supports using the 4 M6 x 50mm Bolts included. DO NOT TIGHTEN. The open side goes to the inside, and you should be able to read L7 logo from the outside.



3. Place Rack on top of supports, and install the 10 bolts into the supports. Using a 6mm Allen head, and 10mm wrench, tighten 10 colored bolts.
4. Tighten the 4 bolts holding the rack supports down to the plastic. Enjoy!

