

Can Am Outlander Gen 1 Max Frame Metal Floor Boards

1. Start by removing the factory plastic floorboards, you will need to take the bolts connecting the fenders to the floorboards off as well as the bottom mounting bolts that hold the foot peg on. On max frame models, you will also need to unbolt the passenger footrest / hardware. Note you will need to save the factory hardware as they will be used to install the new Lucky 7 floorboards.
2. Once you have all the hardware removed, remove the plastic floorboards.
3. Clean under all the plastics and on the bottom support hoops so the floorboards can mount properly.
4. Install the new Lucky 7 Floorboards being careful not to scratch the plastics, they will fit behind the fenders just like the factory ones.
5. Put all hardware in finger tight for now. Adjust the floorboard so it sits straight with the 4 wheeler.
You will have to pull the fenders a little to line them up with the floorboards, this allows for more tire clearance.
6. Use the supplied M6x16mm Bolts to mount the bottom driver foot peg down.
7. Now that all the hardware is installed, tighten everything down.
8. Enjoy