

## Can Am Renegade Gen 1 Metal Floor Boards

---

1. Remove factory plastic floorboards. Unbolt fenders from floorboard uprights, and foot pegs. Do not discard factory hardware as you will reuse it to install the new Lucky 7 Floorboards.
2. Unbolt the factory aluminum floorboard supports that are now visible with plastic floorboards removed. There will be 6 Bolts holding them to the frame. (Keep the M8 flange head nylock nuts from the hardware you remove, as you will reuse them)
3. Install new Lucky 7 Floorboards by putting them in position under the bike and lifting up towards the frame mounts. (Please note that you might have to adjust the mounting bars that are built into the floorboards as sometimes they can be bent during shipping and handling. They are easily adjusted)
4. Once floorboard is in position use the (6) M8x20 Flanged hex head bolts supplied by us, and the factory M8 nylock nuts to mount them. Finger tighten.
5. Install the factory hardware to mount the floorboards to the fender plastics. Finger tighten.
6. Once all the hardware is installed, adjust floorboards so they are level from side to side, and allow clearance of the foot brake. Once level tighten all hardware to factory spec.