

Can Am Renegade Gen 2 Custom Metal Floorboards

1. Remove factory floorboards and footpegs, save the factory hardware as you will be reusing some of it for the install.
2. Remove factory plastic floorboard support, again saving the hardware for install, (right side support you will have to loosen the 13mm nuts that hold the brake lever to the frame enough to pull the support out. Once you remove go ahead and tighten the bolts back down.)
3. Clean support area if desired.
4. Install new Lucky 7 floorboards, using the (8) provided mounting bolts. (4) M6x40mm (4) M6x30mm you will use the M6x40mm bolts closer to the frame and M6x30mm bolts towards the nameplate on the floorboards. You will install the bolts going down, and will need to reuse your stock M6 flange head nyloc nuts from the floorboard and support on the bottom side finger tighten all hardware for now.
5. Use the included M6 button head bolts and nuts to bolt the floorboard to the fenders, finger tighten all hardware for now.
6. Make needed adjustments to align floorboards with bike and allow clearance for belt box and brake lever.
7. Tighten all hardware (double check that you retightened your 13mm nuts on the brake lever)