

Can-Am Outlander Rear Rack Instructions

Tools you will need:

- T-30 Torx Bit
- 10 MM Wrench

1. Using the T-30 Torx Bit, and 10mm wrench, remove plastic rack from rack supports.
2. Once the plastic rack is removed, you will see the 2 silver support brackets that hold up the plastic rack, remove the 2 support brackets. Do not remove the black supports from the 4 wheeler.
3. Use the 2 support brackets provided in the Kit Labeled "L" and "R" for left and right. Attach support brackets parallel to the bike, and use the "L" for the left side, and "R" for the right side. You want the side with 2 holes down, and the side with 5 holes up.
4. Once you have attached the brackets to the 4 wheeler, set the rack on top of the brackets, and using the hardware included, attach all 10 bolts to the brackets.
5. Use the provided velcro to attach the pelican case to the location of your choice.

Call us if you have any fitment issues or installation problems (850)665-4609