

Can-Am Renegade & XMR Rear Rack w/ Storage Case - 500 570 800 850 1000 All Years

Pelican Case Mounting Instructions

If you want to bolt the Pelican case down, you can drill the front two holes in the case using a 3/16" drill bit. Then put the included bolts up through the bottom of the rack into the pelican case.

For additional waterproofing, you can use a dab of silicone on the bolt threads to make it more waterproof.

Thank you for your purchase!