

Honda Rancher 420 Radiator Relocation Kit 2007-2013

The long spacers and bolts come through from the top side right next to the 7, and the L on the Opposite side.

1. Remove Radiator from factory location, don't forget to drain first.
2. Assemble Lucky 7 Radiator Cradle using included M6x1.0 Bolts
3. Place radiator in cradle, bolt top of radiator using the 2 included spacers and long bolts / nuts.
Mach up where coolant lines, and fan wire are going to be ran. using included 4 foot radiator hose, cut in 2 to desired length
4. Cut holes / Extend coolant lines using included hose connectors and clamps.
5. Fill radiator, and bleed. Relocate fill neck if necessary.
6. Last step is to bolt down the radiator kit to the rack.