

Polaris Scrambler 850-1000 Metal Floorboards - All Models

Pre-Install Instructions

1. Remove plastic floorboards from your ATV. Keep all nuts and bolts, as you will reuse them for the install process. Plastic push pins will not be reused, and can be stored for use on other parts of the ATV.
2. Remove the plastic floorboard supports. The floorboard supports are beneath the floorboards and visible once floorboards are removed. You might have to clean the honeycomb material out to access the bolts.
3. Now that the plastic components have been fully removed, clean all mounting surfaces.

Installing the new Lucky 7 Floorboards.

5. When installing supplied hardware, you will insert the M6x16 Button head bolt from the inside of the floorboards (*where your legs will ride towards the tire side*). You will use the 1/4" fender washer behind the plastic fender tabs, and the m6 Flange head nuts. You do not need them if the metal floorboard is behind plastic fender. (*Outside bends on the rear and on the right side board above the side plate where the lateral panel connects to the floorboard*)



6. Wait until all hardware is installed and floorboards are aligned before tightening down all the hardware.
7. Once hardware is tight, double check for clearance and enjoy!