

Low Profile 1 Piece Radiator Relocation Kit Kawasaki Brute Force 750i 2015-2024 and 650 750i 2005-2010

1. Remove radiator from factory location. On some models you may need to remove the fan from the radiator to remove the assembly from the 4 wheeler.
2. Place radiator into kit, placing rubber feet into the radiator kit, then placing the radiator in the rubber feet. Lean the radiator to the top, and secure the radiator to the kit using included spacer, m6 1.0 bolts and Nylock nuts.
3. Figure out where you are comfortable cutting your plastics and running your coolant hoses.
4. Extend Lower hose using included couplers and hose clamps, and make connection to radiator.
5. Repeat Step 4 with the upper hose.
6. On some models, you will need to extend the fan wiring, which will be up to the customer. The positive and negative wires will need to be extended no more than 8".
7. Once the fan is wired, and radiator hoses are connected, fill radiator and complete the bleeding process.
8. Radiator overflow can be relocated, or kept in the stock location.
9. Secure radiator kit to rack using U Bolts
10. Enjoy.

