

CANADIAN  
**DEF Link** Hitachi and John Deere instructions

- 1- Shut machine off and remove key wait 5 minutes then turn off night switch.
- 2- Plug green and white wire into the stock DCU diagnostic plug located on the back of the cab.
- 3- Run a 5amp 24 volt power to the **black –** and **red +**wires on the DEF Link Box. Some units have a spare 6 pin power source by the DCU Stock plug.
- 4- Remove 20 amp DCU Fuse.
- 5- Start the machine D.E.F levels show around  $\frac{3}{4}$  full.
- 6- Mount box securely with self-tapping screws on the back of cab.



This unit does not leave any trace when removed

