

# MICRO MARKETS

**BASIC ASSEMBLY INSTRUCTIONS. YOUR MODEL MAY VARY.**

STEP 1- Attach AA to BB with indicated hardware.

STEP 2- Attach BB to CC & DD with indicated hardware. **Hardware is used to attach 2 spacers in the middle uprights.**

STEP 3- Attach DD to EE with indicated hardware.

STEP 4- Attach EE to FF with indicated hardware.

