



TRANSPONDER MOUNTING INSTRUCTIONS:



1. Attach Transponder pouch on the **RIGHT REAR AXLE TUBE** using zip ties securely around both eyelets of the pouch.
2. Install Transponder into pouch with the silver label facing the racing surface and the flashing LED's pointing to the right side of the car.
3. Close & latch pouch flap.

*There should be NO metal or carbon fiber between the transponder and the racing surface.

**For G3 style transponders, mount the pouch in the vertical position and install the transponder with the silver label facing the left side of the car.