

American Dock Mfg. Inc.
4032 US Highway 2
Florence WI. 54121



1-800-528-5454
americandock.com
e-mail amerdock@americandock.com

BENCH ASSEMBLY

Before placing decks in frame secure 3/8" x 1 1/4" C B, washer and 3/8" nut to frame where you want to place the bench "finger tighten only"
(Note: 3/8" x 1 1/4"CB should have a 3 ft. space between them)



Place decks in frame and place bench over 3/8" x 1 1/4" CB. Fasten with 3/8" nut and washer. Drill 3/8" hole through deck if necessary and place mounting pad under bench frame, mark and drill 5/16" holes.

Remove mounting pad and mount under deck with 1/4" CB washer and nut. Secure bench to plate with 3/8" x 3" cap screws.

