

American Dock Mfg. Inc.
4032 US Highway 2
Florence WI. 54121



1-800-528-5454
americandock.com
e-mail amerdock@americandock.com

Ladder Assembly 2, 3 & 4 step



Unpackage ladder and inspect parts



Bolt steps on using 1/4" x 3/4" carriage bolts, nuts & washers



tighten bolts after all steps are mounted



Apply self adhesive anti-slip tape



Place mounting plate under ladder. Drill 3/8" hole through deck for mounting bolt if necessary. Mark oblong holes and drill 5/16" holes



Remove mounting pad and mount under deck with 1/4" x 2 1/2" CB. nuts and washers. Secure ladder to plate with 3/8" x 3" cap screws.

NOTE! Secure 4' x 4' deck opposite ladder by drilling a 5/16" hole thru the deck and aluminum main frame. secure with 1/4" x 3 1/2" CB. nut & washer.