



SLK R172 / SLC wind deflector-installation instructions:

Loosen both knurled nuts slightly and insert the acrylic retaining lugs into the slots of the roll bar. → Press the wind deflector with the triangular feet evenly and firmly down into the rubber slots. → If necessary, align the acrylic retaining lugs in the roll bar slots a little and then carefully tighten the knurled nuts.

ATTENTION: Never tighten acrylic screws with force !

Care instructions:

Never clean the wind deflector with harsh cleaning agents, solvents or alcohol !!!

Clean the wind deflector with lukewarm water and a few drops of dishwashing liquid. Then dry it with a soft, lint-free cotton cloth (dish towel).

Should a scratch occur, it can be easily removed with an acrylic or plexiglass polishing paste (e.g. Displex), but it also works very well with fine car paint polish.

**Have fun with your new wind deflector
and safe journeys.**

Best wishes from Hamburg

Maik Kohlborn
Windschotts & more

