



## **SLK R170 wind deflector - installation instructions:**

Unscrew the two screws (Torx or Phillips) of the cap holders → pull out the cap holders (sometimes wiggle them a little and twist them slightly) → move the wind deflector to the new position, put both cap holders through the square opening in the wind deflector and carefully screw them tight with the two longer screws provided.

**ATTENTION Please do not tighten the screws with force!**

## **Care instructions:**

**Never clean the wind deflector with harsh cleaning agents, solvents or alcohol !!!**

**Clean the wind deflector with lukewarm water and a few drops of dishwashing liquid. Then dry it with a soft, lint-free cotton cloth (dish towel).**

Should a scratch occur, it can be easily removed with an acrylic or plexiglass polishing paste (e.g. Displex), but it also works very well with fine car paint polish.

**Have fun with your new wind deflector  
and safe journeys.**

Best wishes from Hamburg

Maik Kohlborn  
Windschotts & more

