

Mini Cooper supplement

The adaptors are slightly different than the video now.

Here are what you will need to adapt the OEM fittings:



Note, the left most barb will now press into the OEM connector that did connect to the rear of the valve cover. Here is what it looks like after inserted. You may use a drop of super glue to secure it, but it will seal without.

Supplement for variations in the design through the years. Some will require this style for the CSS, and others the oil fill cap replacement.



