



# Ready For Shrink Wrap

## Check List

- Have your cover on or off at the time of our arrival; shrink wrap installation will commence as the boat appears at the time of our arrival.
- If storing gear in boat, allow a centerline path for necessary installation equipment and movement of personnel during the shrink-wrap installation process.
- Make sure to have your fuel tank treated and topped off to the levels you desire prior to the shrink-wrap installation process.
- If you intend to maintain your batteries with a trickle charger, ensure the cord is in the desired position at the time of shrink-wrap installation.
- Ensure that the motor has been winterized to your requirements and that it is in the desired tilt position at the time of shrink-wrap installation.
- Ensure all measures to rodent proof your boat, i.e., mothballs placed, etc., are completed at the time of the shrink-wrap installation.
- If possible, have your boat nearest to the final location for storage, allowing for 2ft. on all sides and above, for ease of shrink-wrap installation. **NOTE:** if boat must be moved after shrink-wrap installation, let us know if it must travel a short or long distance prior to our arrival.
- Do you require that you be present at the time of the shrink-wrap installation? Your presence is not required at the time of the shrink-wrap installation.