

## RAMPUP INSTALLATION GUIDE

### GENERAL SURFACE CONDITIONS:

SURFACE MUST BE COMPLETELY DRY, DIRT, AND DEBRIS FREE. DO NOT INSTALL IF RAIN HAS OCCURRED WITHIN 24 HOURS PRIOR TO INSTALLATION. ENSURE IRRIGATION SYSTEMS IN CLOSE PROXIMITY ARE DISABLED FOR AT LEAST 24 HOURS PRIOR TO AND AFTER INSTALLATION OF MATS.

PORTLAND CEMENT CONCRETE CURING COMPOUNDS MUST BE COMPLETELY REMOVED BY USING GENERAL CONSTRUCTION METHODS. FOR ASPHALT APPLICATION, USE SAME PREPARATION TECHNIQUES AS CONCRETE.

ONLY APPLY TO SOUND SURFACES OR TO SUBSTRATES IN GOOD CONDITION.

PLACE BARRICADE CONES AROUND INSTALLATION AREAS FOR THE PROTECTION OF THE PUBLIC AND ITS PROPERTY UNTIL SYSTEM HAS DRIED ENOUGH FOR LIGHT FOOT TRAFFIC.

USE SSTD RAMPUP SYSTEM AND SSTD-589 BOND COAT TO COMPLETE THE FOLLOWING PROCESS. **\*SSTD RAMPUP COMES IN 2'X4', 2'X5', 3'X4', AND 3'X5' SIZES, SSTD-589 IS AVAILABLE SEPARATELY IN 32 OZ. AND 40 OZ. QUANTITIES. ASPHALT APPLICATIONS MAY REQUIRE ADDITIONAL SSTD-589.**

### REQUIRED SUPPLIES:



LEAF BLOWER



WIRE BRUSH



2" PAINTER'S TAPE



1/8" V-NOTCH TROWEL



DECK SCRUBBER



2" CHIP BRUSH



3/4" NAP ROLLER



ROLLER FRAME



PAINT EXTENSION POLE

### ADDITIONAL SUPPLIES:



GLOVES



BARRICADE CONES



MEASURING TAPE

**VIEW  
HELPFUL  
TIPS HERE:**



**\*NOTE: AS JOB SITE SIZES VARY, BIGGER PROJECTS MAY NEED MORE SUPPLIES**

## INSTRUCTIONS:

1. PLACE BARRICADE CONES AROUND INSTALLATION AREAS FOR THE PROTECTION OF THE PUBLIC AND ITS PROPERTY.
2. USE A WIRE BRUSH AND LEAF BLOWER TO CLEAN THE DESIRED SURFACE AREA.  
**\*REFER TO PAGE 1 FOR MORE SURFACE PREPARATION DETAILS AND CONDITIONS.**
3. LAY OUT THE MAT TO FIT DESIRED AREA AND INSTALL TAPE 1/4" LARGER THAN ALL PERIMETERS.
4. REMOVE MAT AND THEN EVENLY SPREAD SSTD-589 BOND COAT ON SURFACE USING A V-NOTCH TROWEL. THEN, BACK ROLL BOND COAT ON SURFACE USING A NAP ROLLER. **\*KEEP JOINTS FREE OF ADHESIVE.**
5. INSTALL FITTED RAMPUP MAT ONTO WET SSTD-589 BOND COAT AND SECURE BONDING AROUND PERIMETER USING YOUR HANDS. **\*DO NOT LIFT MAT TO RE-ALIGN.**
6. TO ENSURE MAXIMUM BOND, WALK ON ENTIRE SURFACE FROM THE CENTER OF THE MAT AND MOVE OUTWARD, USE FEET TO KICK TOWARD EDGES OF THE MAT TO HELP STRETCH MATERIAL.
7. USE A DECK SCRUBBER TO APPLY PRESSURE TO BRUSH OUT MAT.
8. USING THE CHIP BRUSH AND SSTD-589 BOND COAT, BEVEL ALL EDGES BY BRUSHING TOWARDS THE MAT. TO ENSURE MAXIMUM BOND, USE YOUR HANDS TO APPLY PRESSURE AND SMOOTH OUT THE MAT STARTING FROM THE TOP CENTER OF THE MAT, DOWNWARDS.
9. REMOVE TAPE BY PULLING AWAY FROM THE MAT AND LET THE EDGES DRY.
10. PLACE BARRICADE CONES AROUND MAT TO PROTECT IT DURING CURE. **\*LIGHT FOOT TRAFFIC IS ALLOWED AFTER 2 HOURS, ALLOW 24 HOURS FOR HEAVY FOOT TRAFFIC.**

**SCAN TO VIEW INSTALLATION VIDEO:**

FOR ADDITIONAL INFORMATION, VISIT: [SAFETYSTEPTD.COM](http://SAFETYSTEPTD.COM) OR CALL OUR TOLL FREE NUMBER: 866-723-3883

