

Converting 2 prong to 3 prong grounded plug

Typical Fender style

WARNING! Always insure the following steps are taken BEFORE working inside any amplifier.

1. Unplug or make sure the amp is unplugged from wall AC.
2. Turn on the power and Stand-By switches.
3. Connect a jumper wire from chassis ground to pin 1 or pin 6 of any preamp tube. We recommend the first tube (12AX7 or 7025 on the far end).
4. Allow stored electricity to drain for a few minutes.
5. If in doubt, refer service to a competent technician.

Follow the diagrams below and you'll find this task to be very easy.

