



**Visit us on the web.
Share your stories pictures, and
ideas on our Facebook Page.**

PO Box 51027, Greater Sudbury, ON, P3C0A3
info@bakerbag.ca

Set-up instructions:

- 1. Unpack BakerBag. Included items are 1 BakerBag Mini, 1 string template, a 1/4" steel drill bit, and 6 - 5/32" s-hooks.**
- 2. Remove platform from baker scaffold. It can be re-installed later.**
- 3. Relocate siderails to desired height above the ground. Typical height is approximately three feet.**
- 4. Identify the center of each side rail. Typical bakers have a center pin. Hook the loop of the string template over the center pin. The template has 3 marks on it to identify the locations for the holes to be drilled. You can verify these with a tape measure on the bag. You will be drilling 6 holes in total towards the side you wish the BakerBag to be located. The holes are drilled to support BakerBag by it's grommets.**
- 5. Use the 1/4" steel drill bit and drill a hole in each marked location directly below the top of the rail and underneath where the platform sits when installed. Install the provided s-hooks in the holes.**
- 6. Unfold and install BakerBag Mini by passing the grommets over the s-hooks. Once completed, the BakerBag seats inside the scaffold assembly and is fully supported by the s-hooks.**
- 7. Inspect assembly. Re-install the baker's platform if needed with the trap door over the BakerBag Mini.**
- 8. We at BakerBag trust our customer's judgement, but please do not overload BakerBag or use it for a purpose that is not intended. It is neither a people carrier, nor should it be used for liquids.**

We look forward to receiving your feedback! Feel free to send us pics. Write a review!

Our customers are industry professionals and their feedback can only help us to make BakerBag the #1 material truck cart and demolition bin.