

Rear View Monitor Installation

- Run the AV wire with the power cables from the rear of the truck to the front cab area.
- Be sure to tie them in a safe location under the truck away from heat source or any possible hazard.
- Route wiring harness from the unit at the back of the truck toward the front of the truck being sure to avoid any heat source or any place the wire could get pinched or come in contact with moving parts of the truck. Secure with zip ties.
- Route the AV wire into the cab of the truck and run up the "A" pillar, then across the head liner to the area near the rearview mirror.
- Snap the monitor over the existing rearview mirror.
- Attach the yellow RCA jack to the yellow RCA jack on the monitor..
- Attach the power connector to the monitor on one end then run the red and black wires down the "A" pillar and connect to a switched 12 volt source and ground.
- The camera in the Mulch Mate gets its power from the accessory 12 volt pin in the 7-pin trailer connector. You must make sure the 7-pin connector has that 12 volts active or the camera will not work.

