

MULCH MATE®

Skid Steer Wireless Remote Harness Installation

- Remove White panel inside chute opening on the left. Remove 4 ½ nuts. Remove panel.
- Disconnect the delay timer upper connection.
- Install skid steer remote above the delay timer until the connector “clicks” into place. The connectors can only go in one direction.
- Test remote operations.
- Reinstall White interior panel with 4 ½ nuts.

