



BY DAWSON MANUFACTURING

Snow Mate 36+ Light Kit

- Snow Mate light kit to be installed in top 2 holes of the knuckle assembly.
- Route the wires so that they do not get pinched or rest on any hot spots when the mower is running.
- Use the provided zip ties for cable management.
- Connect the wiring harness to the positive and negative terminals of the mower battery.
- Mount the on/off switch in an easy to access place on the mower

*If the mower is going to sit for long periods of time, it is recommended to disconnect the light kit from the battery.

