

# EPDM, TPO & PVC Membrane Recycling

888.820.2760



## Step 1

**Call NFR to schedule a site meeting with NFR Field Inspector for the first week of the project.**

## Step 2

**Sweep the deck clear of all stones and debris.**

## Step 3

**Cut and remove seam overlaps along with all metal objects, fasteners, walkways, tarred or patched materials.**

## Step 4

**Fold or roll membrane so it fits **SQUARELY** on a standard wooden pallet (48" x 40"). Stack Pallet to 3' high and secure membrane on pallet.**

## Step 5

**Call in for a pick up. Please provide a minimum of 2 days advance notice. Load truck when it arrives.**

