

888.820.2760

www.nationwidefoam.com



ROLL TPO & PVC

**STEP
1**

SWEEP

Sweep the deck clear of all stones and debris.

**STEP
2**

CUT & REMOVE

Cut and remove seam overlaps along with all metal objects, fasteners, walkways, tarred or patched materials.

**STEP
3**

FOLD EPDM OR ROLL TPO/PVC MEMBRANE

Fold EPDM membrane or roll TPO/PVC membrane so it fits **SQUARELY** on a standard wooden pallet; use a jig if desired. Stack pallet up to 4' high and secure membrane on pallet.

**STEP
4**

SCHEDULE PICKUP

Call in for a pick up. Please provide a minimum of 2 days advance notice. Load truck when it arrives.

✓ THE RIGHT WAY



FOLDED & STACKED CORRECTLY

Neat, square stacks up to 4' high on pallet

✗ THE WRONG WAY



LOOSE & UNSTACKED

Dangerous to transport and not accepted



CALL NFR TODAY TO SCHEDULE YOUR PICKUP!

888.820.2760

— FAST. EASY. RESPONSIBLE. —