



INSTALLING YOUR TOP MOUNT SINKS IS VERY EASY.

- ① **FIRST, PLACE THE SINK IN THE COUNTER TOP OPENING.**
- ② **USING PAINTERS TAPE, OUTLINE THE SINKS POSITION. THEN REMOVE SINK AND MAKE YOUR CUT 3/4" IN FROM THE INSIDE EDGE OF THE TAPED AREA.**
- ③ **THEN, USING ADHESIVE CAULK, RUN A BEAD UP TO THE EDGE OF THE TAPED AREA.**
- ④ **NEXT, SET THE SINK IN PLACE AND REMOVE THE TAPE. CLEAN UP ANY EXCESS CAULK BY USING A DAMP SPONGE.**
- ⑤ **FINALLY, ATTACH THE PLUMBING.**

IF YOUR SINK DOES NOT SET EXACTLY FLAT TO THE COUNTER, ADD WEIGHT INSIDE THE SINK FOR 12 HOURS.

NOTE FOR COPPER SINKS: USE ONLY A WATER-BASED, TRUE ACRYLIC CAULK. SILICONE CAULK IS ACID BASED AND COULD CAUSE A REACTION WITH THE COPPER RESULTING IN DISCOLORATION. A RECOMENDED, COLOR MATCHED, ACRYLIC CAULK IS AVAILABLE ON OUR WEBSITE.

FOR MORE INFO ON INSTALLATION, VISIT
[RACHIELE.COM/INSTALLATION-AND-CARE](https://rachiele.com/installation-and-care)

