



360 SERIES



2022 EDITION

**ASSEMBLY
MANUAL**

360 SERIES ASSEMBLY MANUAL

INTRODUCTION

Follow this guide to assemble a series 360 Hunting Blind from start to finish.

If you purchased a tower stand with your blind, please refer to that assembly guide to assemble the tower first, then come back to finish the setup of the blind on the fully assembled tower stand.



SUPPLIES NEEDED

- T-50 construction stapler
- Utility knife
- Impact Driver
- Caulk gun
- Level
- Flat bar or prybar
- 4 - 8" - 12" Pressure Treated 4 X 4s

PARTS LIST

360 STANDARD

- 1 floor
- 1 floor carpet
- 12 wall panels
- 1 door panel
- 1 roof
- Caulk
- 1 touch up kit
- 1 set of keys

360 PRO

- 1 floor
- 1 floor carpet
- 8 wall panels with standard windows
- 4 wall panels with archery windows
- 1 door panel
- 1 roof
- Caulk
- 1 touch up kit
- 1 set of keys

360 PRO XL

- 1 floor
- 1 floor carpet
- 8 wall panels with standard windows
- 6 wall panels with archery windows
- 1 door panel
- 1 roof
- Caulk
- 1 touch up kit
- 1 set of keys

SAFETY DISCLAIMER

At no time shall 360 Hunting Blinds be liable for any accidents due to normal or improper use of blinds or tower stands.

We recommend that you follow standard safety procedures when entering and exiting the blind, or climbing or descending the ladder.

Always use a gear rope to raise and lower your equipment into the blind.

Always use the handrail with both hands when climbing the ladder.

Never use the door handle to pull yourself onto the platform or stabilize your entry and exit.

STEP 1

INSTALL THE LEGS

Install 8" – 12" 4x4s into the pockets on the floor and secure with 3 – 3" deck screws per foot.

If you purchased a tower stand you may skip this step.

STEP 2

INSTALL THE CARPET

Align the carpet roll to the edges of the blind floor and begin fastening with the T50 Construction Stapler. Work from one end of the floor to the other, working out the wrinkles and continually aligning the edges while going along. If some carpet overhangs past the edge of the floor, use a utility knife to trim the carpet so it is no longer overhanging.



STEP 3

INSTALL THE FIRST PANEL

Set the first panel into place. Have one person hold the top of the panel while another person aligns the bottom.

Make sure the corners of the panel match with the corner of the floor and that the panel doesn't gap away from the floor.

Use a screw to secure the panel to the floor from the inside.



STEP 4

CAULK PANEL EDGE

Run a 3/8" bead of caulk along the leading edge of the first panel. Make sure it's right along the outside of the panel right at the point where the second panel will join up to the first. Remember, the better the seal the longer the blind will last!



STEP 5

INSTALL WALL PANELS

Start at the top of the panel, align the tops and outsides of the panels to make sure they are even. Work the panels to align the outside edges and fasten the panels together with a screw at the top. Then, while working from top to bottom, keep everything aligned and run two more screws to secure the panels together.



STEP 6

REPEAT

Repeat steps 4 and 5 for the remaining panels except the last wall panel and the door.



STEP 7

LIFT THE ROOF

Lift the roof to the top of the blind and rest it on top of the walls.

Balance it on the back walls of the blind far enough to make room for installing the remaining wall panel and door panel.



STEP 8

INSTALL THE LAST PANEL

Now that the roof is resting on top of the walls and set back out of the way, caulk and install the final wall panel.



STEP 9

INSTALL THE DOOR PANEL

With the roof and wall panels in place it's time to install the door. Caulk both wall panels, then set the door panel in place and fasten like the other wall panels. If you fastened any wall panels to the floor, remove those screws for this step so you can shift wall panels for a tighter seal to the door.



STEP 10

FASTEN THE ROOF

Center the roof on the blind.

Start above the door and screw through the top of the wall panel into the roof panel with SHORT screws

Align the panels with the roof by pushing and pulling on each panel as you work your way around the blind aligning the panel joints with the joints in the roof.

Use plenty of screws to make sure the roof can't come off.



STEP 11

FASTEN THE WALLS

If there are wrinkles in the carpet, use a flat bar or prybar to lift the wall panels and push wrinkles back out. Then fasten the wall panels to the floor with several screws.



STEP 12

TOUCH UP

Use the touch up paint to touch up any nicks or scratches that can occur during setup. Any unpainted siding has more risk of rot than painted siding so be particular when painting.