#### **Table of Contents**

Polycom VVX without Admin Password

Polycom VVX with Admin Password

Polycom IP with Admin Password

Polycom IP without Admin Password

Grandstream

Firmware Flash / Reset

Cisco SPA

Yealink

SNOM D Series

#### Scope:

The following steps will allow you to factory reset the following SIP phones.

#### Requirements:

Some phones & firmware may require admin password to reset. It is recommended to ask your service provider or phone vendor to provide these password prior to resetting them.

## Polycom VVX without Admin Password

- 1. Reboot the phone
- 2. When you see Starting Application, press cancel to interrupt press Cancel
- 3. Immediately press and hold the 1, 3, and 5 keys until Enter password to reset settings appears
- 4. Use the MAC address as the password. This can be found on the back of the phone
- 5. Your phone is now factory reset and the default admin password should be 456.

## Polycom VVX with Admin Password

- 1. Reboot the phone by press and hold the dial pad keys **0**, **1**, and **3** all at once for around three seconds or until you hear a confirmation tone.
- 2. Next press and hold the dial pad keys 1, 3, and 5 simultaneously until you are prompted to enter a password.
- 3. Then enter your administrator password to factory reset. Once this is done, the default admin password will be 456.

I DIYODILLI VYIGI / GOLLIILLI GOOVYOLG

- Press Menu
- 2. Navigate to Settings > Advanced.
- 3. Once prompted for a password, enter your admin password.
- 4. Select Admin Settings
- 5. Navigate to Reset to Default then select Reset to Factory
- 6. Your phone is now factory reset and the default admin password should be 456.

# Polycom IP without Admin Password

- 1. Reboot Phone
- 2. Immediately press and hold these buttons simultaneously:
  - If your phone is either a SoundPoint IP 320, 321, 330. 331, 335, 430, and 450, SoundStation IP 5000 or 7000 or Soundstation Duo, press and hold 1, 3, 5, and 7 keys.
  - If your phone is either a SoundPoint IP 301, 501, 550, 600, 601, and 650 and VVX 1500, press and hold **4**, **6**, **8**, **and** \* keys.
  - If your phone is a SoundStation IP 6000, press and hold 6, 8, and \* keys.
- 3. Hold buttons until prompted for a password, then enter the MAC address of the phone.
- 4. Select Admin Settings
- 5. Navigate to Reset to Default then select Reset to Factory
- 6. Your phone is now factory reset and the default admin password should be 456.

### Grandstream

- 1. Navigate to Menu > System > Factory Reset
- 2. Press Yes when prompted

#### Firmware Flash / Reset

- 1. Unplug the phone from power (PoE or DC)
- 2. Hold down all of the buttons on the LEFT-hand side of the screen.
- 3. While continuing to hold the buttons, plug power back into the phone.
- 4. When you see "firmware update" on the screen, you can let go.

The phone should reinstall its firmware from here.

### Cisco SPA

- 1. From the handset press the **Setup** button
- 2. Scroll to Factory Reset (14)
- 3. Press Select
- 4. Press the OK button
- 5. The phone will reboot in a factory reset state.

- 1. Press and hold the OK button until the message Reset to factory? appears
- 2. Press Yes
- 3. Once it restarts, the phone will be factory reset. The default password will be admin.

## **SNOM D Series**

- 1. Log in to the Phone UI
- 2. Navigate to Advanced -> click Update tab
- 3. Click the **Reset** button, then click **Yes**